


4510 WIRING DIAGRAM



Wire Color	Symbol	Color
W	White	White
B	Black	Black
R	Red	Red
Y	Yellow	Yellow
G	Green	Green
L	Blue	Blue
Br	Brown	Brown
Lg	Light Green	Light Green
O	Orange	Orange

Position	W/R	L	B	W/L	W/R
Auto	○	○	○	○	○
OFF	○	○	○	○	○
Manual	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○


Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○


Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○

Position	W/R	L	B	W/L	W/R
OFF	○	○	○	○	○
ON	○	○	○	○	○


4510 WIRING DIAGRAM




CABIN WIRING DIAGRAM 1.



CABIN WIRING DIAGRAM 2.



- ▶ Drawing for fixing position of the fuse
- ▶ Wiring diagram of the electric instrument



1	Fuse box
2	3 pieces of fuse blinks
3	Power for the working
5	Units for direction Signal relay for the power
6	PTO monitor PTO safety relay
7	Coupler for the power Max rated ampere
8	Coupler for the trailer

A	Head lamp	12V45/45W
B	Direction signal lamp	12V21W
	Stop lamp back light	21/5W
C	Meta panel light	12V3.4W
D	Working lamp	12V35W
E	Direction signal lamp	12V21W
	Side lamp	21V5W
F	Back lamp	12V20W
G	Number lamp	12V10W

Wiring diagram of Independent PTO

