

Chapter VI Appendix

1. Wiring diagram of the electrical system




Fig.6-1 Wiring diagram of the electrical system

1. Battery 6-Q(A)-80
2. Electrical horn DL38-12
3. Front head lamp
4. Double plug socket
5. Silicon rectifying alternator
6. Starter
7. Fuse box BX 505
8. One-position switch
9. Turning signal light
10. One plug socket
11. Rear work light
12. Ammeter 307A
13. Starting switch JK424/JK290
14. Horn relay
15. Horn button
16. Two-position switch
17. Direction indicating light switch
18. Oil pressure gauge
19. Regulator
20. Thermal flasher
21. Counting timer
22. Water temperature gauge
23. Fuel gauge
24. Oil pressure plug
25. Water temperature gauge
26. Fuel sensor
27. Preheater
28. Switch
29. Brake switch

2. Accessories for customers to order

Customers may order and purchase the following accessories of the tractors from our factory according to requirements: